

PRODUCT DATA PACK (PDP)		 
NAME: Airgene Aerosol Disinfectant CODE: RM202	PDP REF: PDP-RM202 v02	

DOCUMENT ISSUE			
ROLE	NAME	JOB TITLE	SIGN & DATE
AUTHOR	Lauren Burns	Senior Microbiologist	 23-Mar-2023
REVIEWER	Dr Chris Plummer	Head of Technology	 23-Mar-2023
QUALITY APPROVER	Megan Bowles	Quality Specialist	 23-Mar-2023
ISSUE DATE	23 MAR 2023	REVIEW DATE	23 MAR 2025

PRODUCT INFORMATION	
PRODUCT NAME	Airgene Aerosol Disinfectant
PRODUCT CODE	RM202
FORMULATION VARIANTS	N/A
SDS REFERENCE	SDS RM202
NOTE: ACTIVE INGREDIENTS AND SAFETY INFORMATION DETAILED IN SDS	
DIRECTIONS FOR USE	1. Check the Safety Data Sheet for required personal protective equipment. 2. Ensure humans and animals have left the room before the product is dispensed. 3. Shut all doors and windows, turn off air conditioning. 4. Place the cannister on a flat, even surface, away from fire alarms and remove the seal. 5. Press and rotate the total-discharge valve and leave the room. 6. Leave the product to act for 60 minutes after discharge is complete. 7. Ventilate the room after use, before people and animals are allowed to re-enter.
APPLICATION AREAS	Operating block, infectious areas, ambulances, medical and veterinary consultancies, warehouses, offices, transport means (planes, trains, buses, cars), laboratories, clean rooms, schools, hotels, air conditioning systems etc
STORAGE CONDITIONS	IMPORTANT: Bottle under pressure. Store at room temperature. Avoid extreme temperatures (higher than 50°C) and direct contact with sunlight. Keep away from ignition sources. Do not keep in a place where high temperatures could be reached under the sun (i.e., vehicles). Do not perforate or burn, even after its use. Do not vaporize it near a flame or incandescent object.
SHELF-LIFE	2 years

PRODUCT DATA PACK (PDP)		 
NAME: Airgene Aerosol Disinfectant CODE: RM202	PDP REF: PDP-RM202 v02	

PRODUCT SPECIFICATION	
APPEARANCE	Liquid (actives) + Gas (Propellant)
COLOUR	N/A
ODOUR	Characteristic
pH	6.50 – 8.50
SPECIFIC GRAVITY	0,784 – 0,804 g/cc (active without propellant)
VISCOSITY	N/A

BACTERICIDAL EFFICACY					
TEST REF	TEST ORGANISMS	TEST CONDITIONS	TEST RESULT	REPORT REF	COMMENTS
EN1276	<i>E. coli</i>	Low soil, 1 min	>5 log reduction	TR_748	N/A
EN1276	<i>E. hirae</i>	Low soil, 1 min	>5 log reduction	TR_748	N/A
EN1276	<i>P. aeruginosa</i>	Low soil, 1 min	>5 log reduction	TR_748	N/A
EN1276	<i>S. aureus</i>	Low soil, 1 min	>5 log reduction	TR_748	N/A
EN1276	<i>S. equi</i>	Low soil, 5 min	>5 log reduction	TR_748	N/A
EN13727	<i>E. coli</i>	Low soil, 5 min	>5 log reduction	TR_748	N/A
EN13727	<i>E. hirae</i>	Low soil, 5 min	>5 log reduction	TR_748	N/A
EN13727	<i>P. aeruginosa</i>	Low soil, 5 min	>5 log reduction	TR_748	N/A
EN13727	<i>S. aureus</i>	Low soil, 5 min	>5 log reduction	TR_748	N/A
EN13727	<i>B. bronchiseptica</i>	Low soil, 5 min	>5 log reduction	TR_748	N/A
EN13697	<i>E. coli</i>	Low soil, 5 min	>4 log reduction	TR_748	N/A
EN13697	<i>E. hirae</i>	Low soil, 5 min	>4 log reduction	TR_748	N/A
EN13697	<i>P. aeruginosa</i>	Low soil, 5 min	>4 log reduction	TR_748	N/A
EN13697	<i>S. aureus</i>	Low soil, 5 min	>4 log reduction	TR_748	N/A
EN13697	<i>Salmonella enterica</i>	Low soil, 15 min	>4 log reduction	TR_748	N/A
EN13697	MRSA	Low soil, 15 min	>4 log reduction	TR_748	N/A
EN13697	<i>Enterococcus faecalis</i> (VRE)	Low soil, 15 min	>4 log reduction	TR_748	N/A
EN14348	<i>Mycobacterium avium</i>	Low soil, 10 min	>4 log reduction	TR_748	N/A
EN14348	<i>Mycobacterium terrae</i>	Low soil, 10 min	>4 log reduction	TR_748	N/A

PRODUCT DATA PACK (PDP)		 
NAME: Airgene Aerosol Disinfectant CODE: RM202	PDP REF: PDP-RM202 v02	

YEASTICIDAL/FUNGICIDAL EFFICACY					
TEST REF	TEST ORGANISMS	TEST CONDITIONS	TEST RESULT	REPORT REF	COMMENTS
EN1650	<i>C. albicans</i>	Low soil, 15 min	>4 log reduction	TR_748	N/A
EN1650	<i>A. brasiliensis</i>	Low soil, 15 min	>4 log reduction	TR_748	N/A
EN13624	<i>C. albicans</i>	Low soil, 5 min	>4 log reduction	TR_748	N/A
EN13624	<i>A. brasiliensis</i>	Low soil, 30 min	>4 log reduction	TR_748	N/A
EN13697	<i>C. albicans</i>	Low soil, 15 min	>3 log reduction	TR_748	N/A
EN13697	<i>A. brasiliensis</i>	Low soil, 15 min	>3 log reduction	TR_748	N/A

VIRUCIDAL EFFICACY					
TEST REF	TEST ORGANISMS	TEST CONDITIONS	TEST RESULT	REPORT REF	COMMENTS
EN14476	<i>Influenza A (H1N1)</i>	Low soil, 15 min	>4 log reduction	TR_748	n/a
EN14476	<i>Vaccinia</i>	Low soil, 5 min	>4 log reduction	TR_748	n/a

CHANGE HISTORY			
PREVIOUS VERSION/REF	CHANGE REFERENCE	CHANGE TYPE	REASON FOR CHANGE
N/A	DCC23.015	NEW	New Product Data Pack for new product.
v01	DCC23.058	MINOR	Change to Product Name